



SOFTWARE CONTROL SERVICES (PTY) LTD

475 King's Highway, Lynnwood
P.O.Box 36675, Menlo Park
Pretoria, South Africa
0102

(t) +27 12 348 7301
(f) +27 12 348 1129
(e) techsupport@softconserv.com
www.softconserv.com

Area-Group Set-up.

Version 0. 1

Prepared by: Michael Davis- Hannibal

Softcon Software Control Services (Pty) Ltd.

7 March 2017



Revision History

| Name | Date | Reason For Changes | Version |
|------|----------|--------------------|---------|
| MDH | 5-Nov-10 | Initial document | 0.1 |
| | | | |

Contents

| | |
|-----------------------------|-------------------------------------|
| 1. Reason for changes | Error! Bookmark not defined. |
| 2. Changes..... | Error! Bookmark not defined. |
| Report.mdb..... | Error! Bookmark not defined. |
| Access.mdb..... | Error! Bookmark not defined. |

1. Fields

An area group is used in the software to assign access rights to tag holders. An area group can be assigned to multiple tag holders or each tag holder could have a unique area group.

Area groups can be found by clicking on the menu bar, clicking **Setup, Area zone group**.

The fields are described below

- **Area:** Reference of the area group
- **Name:** Drop down list of all the area group. To edit an area group the group needs to be selected in the list.
- **Accessible:** placing a tick in the check box will assign access to the zone.
- **Ref:** the reference of the area zone in the area zone setup.
- **Area Zone:** The name of the area zone in the area zone setup
- **Timeout:** Time out limits the time (in minutes) that the card has access to the area zone after entering. If the card does not enter another zone before the time has expired, the card becomes disabled.
- **Time Group:** each zone can have a time group assigned. This requires that the setting be changed in the reader setup.

2. Images

